




# ASSEMBLY INSTRUCTION

ITEM NO.:8389BRW/CHC/DGY-3  
SOFA




Armrests are stored under the seat bottom. Legs are in the component box. Please take out for assembly.


**NOTE: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.**

NO.	DRAWING	DESCRIPTION	QTY
A		Seat	1 PC
B		LSF Armrest	1 PC
C		RSF Armrest	1 PC
D		Backrest	1 PC
E		Plastic leg (Φ6cm xH 15cm)	4 PCS
F		Plastic washer (Φ5cm)	4 PCS


# STEP 1:




# STEP 2:




**STEP 3:**




**STEP 4:**



**STEP 5:**



## COMPLETED



### Care Instruction for PU Furniture:

In order to maintain the original appearance of your PU, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and airconditioning outlets. Sunlight and or exposure to heating and airconditioning outlets will fade/damage PU.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connections are tight, Re-tighten if necessary.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.