

## **ASSEMBLING INSTRUCTION**

ITEM NO.: 8489BLK/ BEG-1PB PUSH BACK RECLINING CHAIR

A

Hardware pack is stored at the bottom of chair. Please take out for assembly.


NOTE:Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.


#### COMPONENT LIST


NO.	DRAWING	DESCRIPTION	QTY
A		Seat	1 PC
В		Backrest	1 PC
С	20 50	RSF wooden leg	1 PC
D	00 00	LSF wooden leg	1 PC

### HARDWARE LIST


PART	DRAWING	DESCRIPTION	QTY
Е		L-shaped wrench M6x73mm	1 pc
F		Bolt M6x30mm	4 pcs
G	0 0	Metal plate 40x34x50(mm)x3mmT	4 pcs
Н		Bolt M6x16mm	16 pcs
ı	610	Mouting plate 98x47x13(mm)x2mmT	4 pcs










0 0










# COMPLETED.



### Care Instruction for Faux leather Furniture: In order to maintain the original appearance of your Faux leather furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage Faux leather.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connection are tight, Re-tighten if necessary.



For item use on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.